

Instructions on performing software updates with the devices

- 1.VITA VACUMAT 6000 M**
- 2.VITA VACUMAT 6000 MP**
- 3.VITA ZYRCOMAT 6000 MS**
- 4.VITA vPad comfort**
- 5.VITA vPad excellence**

Dear Customers and Users,

we are writing to let you know about the new software update for your VITA device as well as to ask you to install the updates on your device in accordance with the instructions below.

Should you have any questions regarding this update, please contact your regional service partner for VITA devices. You can also contact VITA Equipment servicing at:

- Tel.: +49 (0)77 61 / 562 – 101, 105 or 106
- Fax: +49 (0)77 61 / 562 – 102
- Email: instruments-service@vita-zahnfabrik.com




1. General procedure





1. Download the software update from the Internet and save it to a USB flash drive
2. Create a backup copy of your own users or materials and programs
3. Install the software update for VITA VACUMAT 6000 M, VITA VACUMAT 6000 MP and VITA ZYRCOMAT 6000 MS
4. Verify / enter device data and settings
5. Reinstall your own (previously stored) users or materials and programs
6. Registration for the VITA Update Messenger





2. Prerequisites for download and installation

- a) Internet access
- b) Empty USB flash drive






1. Download the software update from the Internet and save it to a USB flash drive







Step	User inputs	Function
1	Launch www.vita-zahnfabrik.com in the web browser	
2	Select "Services" + "VITA Update Messenger"	
3	Select "To newsletters"	







Step	User inputs	Function
4	Select the latest newsletter	
5	Select the required update	
6	Select "Save"	
7	Select the path for the USB flash drive (removable disk), then "Save"	
8	Select "Open Folder"	
9	Double-click on the file	

10	Double-click on the file	
11	Confirm the "Start" button	
12	Confirm the message with "OK"	
13	The USB flash drive now contains the following files	
14	Remove the USB flash drive from the computer	

2. Create a backup copy of your own users or programs

Step	User inputs	Device function
1	Switch on the device using the main switch	The lift moves to the lower position
2	Insert an empty USB flash drive into the side of the VITA vPad	The display shows: 
3	Press the  tab	The display shows: 
4	Press the  button	The display shows: 


5	Select the user to be exported	<p>The user is highlighted</p> <p>The display shows:</p> 
6	Press the  button	<p>The display shows:</p> 
7	Press the  button	<p>The user is stored to the USB flash drive</p>
8	Press the  button	<p>The display shows:</p> 

3. Install the software update for VITA VACUMAT 6000 M, VITA VACUMAT 6000 MP and VITA ZYRCOMAT 6000 MS		
Step	User inputs	Device function
<p style="text-align: center;"><u>Important note:</u> The lift must be in the lower position + No program (incl. standby) active</p>		
1	Insert the USB flash drive with the software update into the side of the VITA vPad	<p>The display shows:</p> 
2	Press the  tab	<p>The display shows:</p> 
3	Press the  button	<p>The display shows the update process</p> <p>Once the update has been completed the display shows "Update completed"</p>
4	Confirm the message with the  button.	<p>The display shows:</p> 

Important note:

The USB flash drive must remain inserted throughout the entire installation procedure and no other buttons may be pressed!

The installation is concluded when the start screen is shown again



IMPORTANT:

The actual firing chamber temperature as well as the preset standby temperature must be shown!

If "0 °C" is shown here for both of these values, then the installation of the update is not yet completed!

Information:

If the message "**No new update found**" is shown when the



button is pressed for the first time,

then confirm this message with the



button and press the



button again.

Updates when operating multiple furnaces







In order to perform a software update when operating multiple furnaces, the devices must be updated separately, i.e. the VITA Switchbox must be removed and the VITA vPad connected to each individual device one after the other and the update then performed in accordance with these instructions.

In order to retain the desired device display sequence on the VITA vPad, the devices should be switched on in the corresponding sequence using the main switch after the software update.






Alternatively, sorting can be carried out using the multi-furnace settings on the VITA vPad after the software update.







Please note that once the new software has been installed, the device data and device settings must be verified or entered in the service area on each individual device! For corresponding details, see the following section in these instructions.

4. Verify or enter device data and settings

Step	User inputs	Device function
1	Press the  tab	<p>The display shows:</p> 
2	Press the  button	<p>The display shows:</p> 
3	<p>Using the version no., please check whether the new software has been correctly installed.</p> <p>If the current version is not shown, the update must be repeated!</p>	
4	Then confirm with the  button.	<p>The display shows:</p> 

5. Reinstall your own users or materials and programs



Step	User inputs	Device function
1	Insert the USB flash drive with the users or programs that have been previously stored into the VITA vPad	<p>The display shows:</p> 
2	Press the  tab	<p>The display shows:</p> 
3	Press the  button	<p>Display shows (without your user):</p> 
4	Select the user to be imported	The user is highlighted

5	Press the  button	<p>The display shows:</p> 
6	Press the  button	<p>Display shows (with your user):</p> 
7	Press the  button	<p>Display shows (with your user):</p> 

Information:

In order to import the materials and programs, please proceed exactly as described here. To do so, press the relevant tabs in the menu.

6. Registration for the VITA Update Messenger

Step	User inputs	Function
1	Launch www.vita-zahnfabrik.com in the web browser	
2	Select "Services" + "VITA Update Messenger"	
3	Select "Subscribe right now" and then follow the registration steps.	